

Attaching the Enclosure

Attaching the Enclosure to the Frame of the Kitty Kat Kabana:

- A** Erect the Frame of the Kitty Kat Kabana. (*See Separate Instructions*)
- B** The next steps will be easier if the ABS Plastic Pan is not loose inside, so temporarily remove it. Lay the Screened Enclosure out on a flat surface. Set the Kitty Kat Kabana Frame on the one end with the opening facing the padded edge of the Enclosure. Position it all the way to the edge of the Enclosure and up against the padding. Fasten the Velcro strips around the lower wires of the frame to hold the Enclosure in place.



- C** Wrap the Enclosure around the perimeter of the Frame. When you get to the top, feed the Aircraft Cables each through their respective Grommets. You may have to squeeze the loop you put into the end of the Cables to allow them to pass through their respective Grommets. They will pop right back into shape.



For the last side, it would be easiest if you rotate the Frame with attached Enclosure onto its side so the last section of the Enclosure can be fastened to the section you started with.

- D** Pull the Enclosure taut and connect the Velcro to the starting side.



Attaching the Enclosure

- E** Connect Velcro fasteners on the front panel (*the panel on the opposite side from the opening*) to the mating Velcro on all three free sides of the Enclosure. Note, the bottom Spring Loaded Cable (*if used*) will pass through between the Bottom and Front panels where they overlap.



Finish by folding the corners over and fastening their Velcro pieces together.



- F** Pull the top Sun Shade over the top of the Enclosure and hold in place using the mating Velcro fasteners. This will prevent the wind from catching it and will hold it neatly in place.



Attaching the Enclosure

- G** The final step is to fasten the Velcro straps on the perimeter padding of the Enclosure to the Frame of the Kitty Kat Kabana and put the Plastic Tray back inside.



- H** The Kitty Kat Kabana with its Screened Enclosure is ready to be suspended from the two “J” Clips using the Aircraft Cables. Note - the Plastic Tray has not yet been placed back inside so the sturdy custom metal Frame can be seen.

